Etekcity® 16000mAh Power Bank - User's manual

Introduction

Thank you for purchasing the Etekcity power bank. This power bank is a great way to ensure that you have a backup power source for your laptop, phone, MP3 player, tablet, GPS, or other rechargeable electronic device. Add convenience to your life with the Etekcity power bank.

Operating instructions

Charging

- To charge the power bank, plug the included power supply into the wall and connect it to the power bank. When charging, the indicator lights will blink. When the lights stop flashing, charging is finished. Five indicator lights indicate the battery level – you can check the battery level when not charging by pressing the button on the power bank.
- The power bank may become warm while charging; this is normal. Please recharge every three months when not in use to maximize battery health.

Using the power bank

- The power bank will automatically turn on or off when devices are plugged in or removed.
- To use the power bank, simply turn on the power bank and then attach the devices you wish to recharge or use with the power bank.
    - For 5V USB devices, connect the proper plug adapter to the USB cable and plug into your device and the power bank's USB port. You can also use USB cables you already have.
    - For laptops or other 12/16/19V devices, move the switch to the appropriate position for your device, as labeled on the power bank. Connect the proper power plug adapter to the power cable and plug into your device and the power bank's output port.
- Clean the power bank with a moist cloth and dry immediately. Do not use harsh cleaners on the product. Keep away from moisture and heat sources. Do not disassemble or improperly dispose of the power bank.

Specifications

- Power input: DC 18.5V 2A (from wall: AC 100-240V)
- Power output: DC 12/16/19V 60W, USB DC 5V 2.1A max.
- Battery: Li-polymer, 16000mAh
- Dimensions: 185 x 125 x 14mm
- Weight: 527g

Package includes

- Etekcity power bank
- Power supply
- Power cable with 10 adapters (Sony 6.0x1.4,Toshiba 6.0x3.0, IBM / Acer/ Toshiba 5.5x2.1, Asus / HP 4.75x1.7, Acer 5.5x1.7, Acer / BenQ 4.0x1.7, Samsung 5.5x1.0, Dell / HP 7.4x5.0x0.6,IBM / Sony 7.9x5.4x0.9, Dell 3P)
- USB cable with 10 adapters (Nokia small head, Mini USB, Micro USB, iPhone, Sony Ericsson K750, PSP, NDSl, Samsung i900, LG KG90, Samsung D800)
- User's manual